
GROOMERS WORLD PRO

SERVICE MANUAL

SINGLE MOTOR FORCE DRYER WITH HEAT



GW SMD-2800


Product Specifications

ITEM NO.	MAX POWER	HEAT POWER	BLOW FORCE	MAX SPEED	MAX AIRFLOW	TEMPERATURE RANGE	NOISE	NET WEIGHT	RATED VOLTAGE / FREQUENCY
GW SMD-2800	2800W	600W	1000g	525MPM 66,000FPM	7 CBM 290 CFM	RT+42℃/107℉ (DISTANCE FROM AIR OUTLET)	74-87 dB	4.85kg 10.7lb	220-240V 50/60Hz

Note: values may vary depending on the operating state of the dryer.

GW SMD-2800

The Groomers World Single Motor Force Dryer is designed specifically for professional dog grooming, delivering powerful, consistent airflow to assist with efficient coat drying and the removal of excess water. Combining reliable performance with adjustable airflow and heat settings, this dryer provides groomers with greater control to accommodate different coat types and drying requirements.



- Setting 1 - Motor Heat: Uses airflow naturally warmed by the motor to remove excess water from the dog's coat and assist with efficient drying.
- Setting 2 - Additional Heat: Activates the additional heating element to provide warmer airflow when required, particularly in cooler environments.
- Switching Between Settings: Settings 1 and 2 can be selected during operation according to the drying requirements and the dog's comfort.


ONE YEAR WARRANTY

Groomers World dryers are covered by a 12-month warranty against manufacturing defects in materials and workmanship from the date of purchase. If a manufacturing defect is confirmed, we will arrange an appropriate repair or replacement in accordance with your statutory rights.


Warranty exclusions: Normal wear and tear; consumable carbon brushes; and damage caused by misuse, improper maintenance, blocked filters, restricted airflow, accidental damage or unauthorised repairs or modifications are not covered by the manufacturer warranty. Motor damage caused by excessively worn carbon brushes not replaced when required is excluded where inspection confirms this caused the failure.

Proof of purchase may be required. For assistance email info@groomersworld.co.uk. This warranty does not affect your statutory rights.

Components & Accessories



Assembly



Turn clockwise to assemble the nozzle, handle, and hose



Turn clockwise to attach the hose connector, then slide the tab to lock in position

Maintenance





1. Clean the sponge filter with air or warm, soapy water. Allow it to dry completely before refitting.
2. Switch off and unplug the dryer before cleaning. Wipe with a slightly damp cloth and mild cleaner.
3. Check the filter regularly and keep the air intake clear to prevent overheating and motor damage.
4. For maintenance guidance, visit our YouTube channel: @GroomersWorld.

Product Disposal


Do not dispose of this product with household waste. Take it to an appropriate electrical recycling collection point. Contact your local council for UK recycling guidance.

Directions for Use

- Twist clockwise to lock the hose in position on the front of the dryer and attach a drying **nozzle(optional)**.
- Connect the dryer directly to a suitable UK wall socket using the supplied 13A fused plug.
- Turn the speed dial down to the lowest setting and secure or hold onto the hose, then turn on the power switch to start airflow.
- Twist the speed dial to the lowest setting before turning off the power switch. Then, unplug the dryer after use.
- Ensure the hose and nozzle are firmly attached before operating to prevent sudden shifting when airflow begins.
- Place the dryer on a stable, flat surface to prevent tipping or accidental falls during use.
- Inspect the power cord and hose before each use; discontinue use immediately if any damage is present.

Safety Information

- Connect the dryer directly to a suitable UK wall socket using the supplied 13A fused plug.
- Ensure the electrical supply is compatible with the appliance rating label.
- Do not plug the force dryer into an outlet with other appliances.
- Secure or hold onto the hose and nozzle before starting airflow, as it may shift suddenly with the initial burst of air.
- Always turn the speed dial down to the lowest setting before turning the dryer on or off.
- Never insert pins or metal accessories into the machine, for risk of electrical shock and short circuiting.
- Do not reach inside the hose connection port or touch internal components.
- Safely secure the dryer to avoid drops, falls, and external damage.
- Do not use this dryer if you have a history of cardiomyopathy, a pacemaker, or other heart conditions without medical approval.
- If you experience any issues with the dryer, contact Groomers World at info@groomersworld.co.uk for troubleshooting assistance and advice on the next steps. Do not attempt to disassemble or repair the appliance yourself.
- If the power cord or hose becomes damaged, stop using the dryer immediately and contact Groomers World at info@groomersworld.co.uk for further assistance. Do not continue using the appliance until the issue has been resolved.
- This appliance can only be used by individuals aged 18+ or trained professionals.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children.
- Must be installed with a residual current device (RCD) having a rated residual operating current not exceeding 30 mA in the electrical circuit supplying the bathroom. Ask your installer for advice.
- Do not operate the appliance if it has been dropped, exposed to water, or shows signs of malfunction.



- Do not plug the dryer into shared outlets, adapters, extension leads, or power strips.
- Never allow the dryer, power cord, plug, hose, or accessories to get wet.
- Do not operate the appliance outdoors or in damp or high-moisture environments.
- Inspect the power cord, plug and hose regularly for signs of damage. If any damage is identified, discontinue use immediately and contact Groomers World at info@groomersworld.co.uk for advice before using the dryer again.
- Do not insert metal objects, tools, or grooming accessories into any part of the appliance.
- Do not clean or handle the appliance with wet hands.
- Keep hands, loose clothing, long hair, and accessories away from air inlets.
- Place the dryer on a stable, flat surface to prevent falls and damage.
- Ensure adequate ventilation around the dryer during operation. Keep all air intakes and outlets clear of obstructions and regularly clean the filters. Restricted airflow or inadequate ventilation may cause the dryer to overheat, potentially resulting in motor damage or premature failure.
- Unplug and allow the dryer to fully cool before cleaning.
- Do not apply solvents or liquid cleaners directly to the appliance.
- Store the dryer in a dry, ventilated place away from moisture, chemicals, and heat sources.
- The expected service life of the dryer is 3 years under normal use and maintenance.
- All repairs must be carried out by a Groomers World-approved service centre or authorised technician. Only Groomers World-approved replacement parts and accessories may be used. Do not attempt to disassemble, modify or carry out unauthorised repairs on the appliance.
- Always unplug after every use.
- Do not leave the dryer running unattended at any time.
- Keep the dryer away from flammable items such as towels, bedding, sprays, or chemicals.
- Do not place the dryer on soft surfaces (carpets, mats, towels) that may block ventilation.
- Ensure pets cannot chew or pull the power cord during use or storage.
- Do not cover the dryer or obstruct ventilation openings during operation.
- Allow the motor to cool for several minutes after extended use to prevent overheating.
- Do not operate the dryer while standing in water or on a wet floor.
- Turn off and unplug the appliance if the nozzle or hose becomes excessively hot.
- Ensure the hose is securely attached and locked before switching the dryer on.
- Avoid directing airflow into a dog's eyes, ears, or nose.
- Check the appliance regularly for hair or debris build-up and clean after every use.
- Keep the dryer out of reach of unsupervised children and pets.
- Turn off and unplug the unit before replacing or adjusting accessories.
- Do not pull the dryer by its cord or use the cord to lift or move the appliance.
- Avoid twisting, bending, or sharply pulling the hose or power cord.
- Ensure your hands are dry before plugging in or unplugging the appliance.
- Do not use homemade, damaged, or unapproved attachments.

- Only use the appliance for its intended purpose: drying and blasting water from dogs' coats.
- If the dryer produces unusual noises, burning smells or smoke, switch it off and disconnect it from the electrical supply immediately, provided it is safe to do so. Do not use the dryer again. Contact Groomers World at info@groomersworld.co.uk for assistance and advice on the next steps.
- Keep electrical sockets and plugs free from hair, dust, and moisture.
- Keep a copy of this manual in case the product is sold on.
- Go to the product page at www.groomersworld.co.uk for updates and the latest manuals.
- WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

Dryer Accessories List



GW PDS-01

Stand and Hard Pipe Combination Set
Mobile stand with a sturdy rigid pipe, compatible with GW SMD-2800 and GW DMD-2400 dryers.



GW PDS-04

Stand and Hard Pipe Combination Set
Mobile stand with a sturdy rigid pipe, compatible with GW DMD-3000 only.

The Entire Series of Force Dryer



GW SMD-2800



GW DMD-2400



GW DMD-3000

Welcome to GW Equipment

Your Go-To Grooming Manufacturer

GW Equipment Ltd, trading as Groomers World, is a specialist supplier of professional dog grooming equipment, providing reliable, high-quality products designed to meet the demands of grooming salons, training establishments and professional groomers.

We are committed to delivering dependable equipment, competitive pricing and excellent customer service. From product selection and quality assurance through to packaging and delivery, we aim to maintain high standards at every stage.

We understand the importance of reliable equipment in a professional grooming environment. Our goal is to provide practical, durable solutions that support groomers in their daily work, helping them deliver consistent results while maintaining the comfort and wellbeing of the dogs in their care.

Quality | End-to-end control, from manufacturing to shipping

Loyalty | Our expert, passionate team has a big reach

By and For Pet Groomers

Our team values expertise, ideas, and requests from the grooming community. That's why every GW Equipment design is proudly tested and refined based on feedback from working groomers and salon owners.

Need help? Contact us at **Info@groomersworld.co.uk.**

GROOMERS WORLD PRO

GROOMERS WORLD PRO

Info@groomersworld.co.uk

GW Equipment Ltd.

Address: Unit 11 Sunflag Business Park,
Durham, UK, DH1 1TN

Website: www.groomersworld.co.uk

Email: Info@groomersworld.co.uk