



Large Accordion Electric Lifting Pet Grooming Table **GW GT-899P**



1. TECHNICAL SPECS

GT-899P Pro			
Table Height(excluding arm)	12 – 45.9 in 、 30.5- 116.5 cm	Tabletop Size	47.2 x 23.6 x 0.7 in 、 120 x 60 x 1.8 cm
Height Change Speed	0.75 in/s 、 2 cm/s	Tabletop Material	Water-proof Wood Plastic Composite
Lift Mechanism	Electric Actuator 6000N	Power Rating	110 – 240V 、 Max 8A / 190W
Max Weight Capacity	265 lb 、 120 kg	Product Net Weight	134.8 lb 、 63.5 kg

2. CONTACT INFORMATION

Thank you for choosing Groomers World. This guide will help you get the best from your new grooming table by providing important information on setup, operation, care, and maintenance to ensure safe use and long-lasting performance.

 Website: www.groomersworld.co.uk

 Email: info@groomersworld.co.uk

 Facebook: Groomers World

3. GENERAL GUIDANCE

UPON ARRIVAL

Please carefully inspect your grooming table and review the packing list upon delivery. If you notice any missing parts or damaged components, please contact Groomers World immediately at info@groomersworld.co.uk.

CLEANING, CARE AND MAINTENANCE

Groomers World grooming tables are designed for professional use. Regular cleaning and routine maintenance will help keep your table operating safely and efficiently while maintaining its appearance and performance.

WORKING CONDITIONS

Allow the linear actuator system to rest for 15 minutes after prolonged continuous operation.

Avoid operating the table in extreme temperatures below 4°C (40°F) or above 40°C (104°F).

ROUTINE INSPECTION

- Complete a visual inspection of the table, controls, and linear actuator system before use.
- Check all screws, bolts, bushings, pins, and fasteners for signs of wear, looseness, or damage.
- Inspect the linear actuator system and moving parts for signs of wear, damage, or abnormal operation.
- Verify that all adjustable components are secure and functioning correctly.
- Observe the table during operation and check for any unusual noises, vibrations, or movement.

LOAD CAPACITY

- Never exceed the maximum safe working load specified for your grooming table.
- Overloading the table may damage the linear actuator system and could invalidate the warranty.

ELECTRICAL SAFETY

- Disconnect the power supply before carrying out any maintenance or cleaning procedures.
- Do not operate the table if the power cable, plug, foot control, or electrical components are damaged.

NON-ROUTINE MAINTENANCE

- For safety reasons and to maintain warranty coverage, any faults relating to the linear actuator system, control system, or electrical components must be reported to Groomers World.
- Maintenance personnel must be familiar with the contents of this instruction manual and should only use genuine Groomers World replacement parts and components.

WARNING

The operator must read and fully understand this instruction manual before using the appliance. Failure to follow the operating and safety instructions may result in serious injury or death.

4. PACKING LISTS


STEP 1

T-shaped screw
Used to secure the grooming arm



-  Hold to up
-  Hold to down

STEP 2



Fold the pedal up when not in use.
Press it down to the right to engage the wheels and move the table easily.



Operating Procedure

- Check the product for any damage before use.
- Switch on the power supply and lower the table to a suitable height for safely loading the dog.
- Carefully place the dog onto the table and adjust the height as required for comfortable working conditions.
- Never use or operate the table with the wheels engaged or in the lowered position.
- Ensure all wheels are fully retracted and locked before loading a dog or adjusting the table height.
- Ensure the dog is securely positioned and, where appropriate, restrained before operation.
- Ensure the surrounding area and floor are clean and dry before making any height adjustments.
- Switch on the power supply and adjust the table to the required working height.
- Avoid unnecessary or continuous operation of the lifting mechanism.
- Ensure the dog remains centrally positioned on the table during operation.
- Once grooming is complete, lower the table to a safe height for removal.
- Switch off the power supply once the desired height is reached.
- Carefully remove the dog from the table.

**** NEVER LEAVE ANIMALS ON UNATTENDED. ALWAYS MONITOR FOR SAFETY ****

6.Grooming Table Configuration




Hook*5



Storage Box

7.TABLE DIMENSIONS



Safety & Operating Instructions

- This appliance is intended solely for professional dog grooming. It must not be used for lifting people or for any other purpose.
- This appliance may only be operated by trained professionals aged 18 years or over.
- Children must not operate or play with the equipment.
- Do not exceed the maximum load capacity of 120 kg. Ensure the dog is positioned centrally at all times.
- Ensure the unit is installed on a stable, level surface and that all components are correctly assembled prior to use.
- Inspect all structural components, including welding points on the lifting frame, before each use to ensure there are no signs of damage, cracking, or fatigue; do not operate the appliance if any defects are identified.
- Inspect painted surfaces regularly; any damaged or chipped paintwork must be restored immediately to prevent corrosion and deterioration of structural components.
- Ensure all wheels are fully retracted, raised, and locked before loading a dog onto the table or operating the lifting mechanism. Never use or operate the table with the wheels engaged.
- Ensure any grooming arm, hook, restraint point, or attachment is securely fitted before use. Inspect for damage or excessive wear before each use and do not use if defects are found.
- Do not use hooks, grooming arms, or restraint points to support, suspend, or lift the dog's weight.
- Ensure all tools and accessories stored in the storage box are secured safely. Do not leave scissors, blades, combs, or other sharp objects protruding from the storage box where they may cause injury.
- Always ensure the surrounding area and floor are clean and dry before use to reduce the risk of slips, trips, or electrical hazards.
- Ensure all electrical connections are protected by an IP66-rated socket & suitable waterproof cover when operating.
- Electrical components must be protected from water ingress at all times. Do not allow water to come into contact with plugs, sockets, controls, or cables.
- Do not tamper with, interfere with, or attempt to access internal electrical components. Do not insert, poke, or prod objects into any openings, controls, or electrical parts of the appliance.
- Keep hands, feet, and other body parts clear of moving parts, particularly the lifting mechanism, as this may result in crushing or pinching injuries and could result in serious injury or death.
- Never leave a dog unattended on the table and maintain supervision at all times during operation.
- Do not use the equipment if the power cable, plug, transformer, actuator, or foot pedal is damaged.
- Do not connect the appliance to an overloaded circuit or shared outlet where this may present a risk.
- Ensure all cables are positioned safely to prevent damage, strain, tripping hazards, or access by dogs.
- Do not operate the lifting mechanism continuously for more than 2 minutes. Allow a minimum rest period of 18 minutes between cycles to prevent overheating.
- The expected service life of this appliance is 3 years under normal use and maintenance.
- Always disconnect the appliance from the power supply when not in use and at the end of each working day.
- Disconnect from the power supply before cleaning, inspection, or maintenance.
- Clean using a dry or slightly damp cloth only. Do not use corrosive, abrasive, or solvent-based cleaning agents.
- Do not use water to clean electrical components, including the controller, foot pedal, or actuator, due to risk of electric shock.
- In the event of abnormal operation, stop use immediately, isolate the appliance from the power supply, and do not attempt to repair or disassemble the unit. Contact your supplier for assistance.
- Do not modify the equipment in any way. Use only approved parts and accessories.
- Ensure the working environment is well-lit, clean, and free from obstacles; always ensure the dog is correctly positioned on the table and not beneath or near moving parts during operation.
- Always use appropriate restraints where necessary to ensure the safety of the dog.
- Regularly inspect the appliance to ensure it remains in safe working condition. All repairs must be approved by Groomers World.
- Ensure all safety labels remain present, clean, and clearly legible at all times; if not, contact us at info@groomersworld.co.uk.
- This manual may have expired. For product updates and the latest instruction manual, visit: www.groomersworld.co.uk

For all warranty information, please contact us at info@groomersworld.co.uk.

Warranty Exclusions

This warranty does not cover faults or damage caused by misuse, neglect, accidental damage, failure to follow instructions, unauthorised repairs or modifications, normal wear and tear, unsuitable operating conditions, improper maintenance, transportation damage after delivery, or use of non-approved parts or accessories. This warranty does not affect your statutory rights under UK consumer law.

Limitation of Liability

To the fullest extent permitted by law, the supplier shall not be liable for any indirect or consequential loss, including loss of profits, revenue, goodwill, or third-party claims. Nothing in this clause excludes or limits liability for death or personal injury caused by negligence, fraud or fraudulent misrepresentation, or any liability that cannot be excluded under UK law.



ELECTRIC LIFTING TABLE WITH WHEELS

Name	Pet Grooming Table	Weight GW/NW	76.2/70.4 kg
Model	GWGT-899P Pro	Input	230V-50Hz
Size	126*65*39-119.5H cm	Max Power	140W
Lifting Height	39-119.5cm	Output	24V=, Max2,0A
Static Load	115 kg	Manuf No	01GW-GT-899P Pro
Lifting Weight	120 kg	Manuf Date	20.06.2026



WARNING
Read and fully understand operator's manual before using this machine.
Failure to follow operating instructions could result in death or serious injury.

MADE IN CHINA

GW Equipment Ltd., Unit 11 Sunflag Business Park,DH 11 TN Durham
info@groomersworld.co.uk



WARNING
Read and fully understand operator's manual before using this machine.
Failure to follow operating instructions could result in death or serious injury.

MADE IN CHINA

GW Equipment Ltd., Unit 11 Sunflag Business Park,DH1 1TN Durham
info@groomersworld.co.uk